


### LX/LX-LC


#### **VON DUPRIN**

941039-00

Switch Retrofit Kit Installation Instructions




#### Step 1 Disassemble the device. (Remove from door if mounted.)







### Step 1 continued Disassemble the device. (Remove from door if mounted.)




\_\_\_\_\_\_




## Step 2 Install Switch







## Step 3 Attach rod

Top illustration is for a 22 Device with a composite action rod only. All others see bottom illustration.





# Step 4 Check the switch for proper actuation



## Step 5 Prepare door for device wiring.

