

# NDEB Retrofit Kit Installation Summary

DISTRIBUTED BY



- Completely remove the existing NDE80 lock from the door - This will prevent any debris from the new installation process from entering and damaging any portion of the NDE80 lock to be reinstalled
- NDE-Series, NDEB Model Door Preparation Template (P519-092) is included with the NDEB Retrofit Kit and should be used to add the required Door Position Switch holes
- NDEB Wireless Lock Installation Instructions (P519-087) are included with the NDEB Retrofit Kit and should be followed for the installation process
- All NDEB Retrofit Locks **MUST** be re-commissioned using ENGAGE. Ensure the latest version of ENGAGE is used for the re-commission process.
  - Best practice is to delete the original NDE80 lock in ENGAGE and then FDR the new NDEB and re-commission