

Specification Chart (transformer is listed at 120VAC input):

Model #	Output	Amp	A	B	C	D	E	F	Approx. Ship Wt.
T2428100	24VAC/100VA	4.16	3.57"	2.56"	2.25"	1.31"	4"	3.625"	1.12 lbs.
	28VAC/100VA	3.57							


Installation Instructions:

1. Mount Transformer in desired location/enclosure.
2. Plug in the AC (120VAC 50 / 60 Hz) to an outlet.
3. Measure output voltage before connecting devices. This helps avoid potential damage.
4. Connect devices to secondary terminals on the transformer.



WARNING: This installation should be made by qualified service personnel and should conform to all local codes and in accordance with the National Electrical Codes.

Fig. 1



Altronix is not responsible for any typographical errors. Product specifications are subject to change without notice.