

## Become a 60 Second *e*<sup>3</sup> SERIES™ Expert

Everything you need to know to build a basic eMerge system in less than a minute.

[www.linearcorp.com/emerge-browser-managed-access-systems.php](http://www.linearcorp.com/emerge-browser-managed-access-systems.php)

### One-Door System


- A** One (1) **ES-1MB**<sup>1</sup> 1-Door, 1-Mullion Mount Reader Essential Access System Bundle (Part # 620-100219)
- B** One (1) **ProxCARD II** 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARD II)



eMERGE  
ESSENTIAL

### Two-Door System


- A** One (1) **ES-1MB**<sup>1</sup> 1-Door, 1-Mullion Mount Reader Essential Access System Bundle (Part # 620-100219)
- B** One (1) **ES-1DLB**<sup>1</sup> Single Door License with Reader Bundle (Part # 620-100221)
- C** One (1) **ProxCARD II** 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARD II)



eMERGE  
ESSENTIAL

### Three-Door System

- A** One (1) **ES-1MB**<sup>1</sup> 1-Door, 1-Mullion Mount Reader Essential Access System Bundle (Part # 620-100219)
- B** Two (2) **ES-1DLB**<sup>1</sup> Single Door License with Reader Bundle (Part # 620-100221)
- C** One (1) **ProxCARD II** 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARD II)



eMERGE  
ESSENTIAL

### Four-Door System

- A** One (1) **ES-4MB**<sup>2</sup> 4-Door, 4-Mullion Mount Reader Essential Access System Bundle (Part # 620-100220)
- B** One (1) **ProxCARD II** 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARD II)



eMERGE  
ESSENTIAL

Linear<sup>®</sup>

800.421.1587  
[www.linearcorp.com](http://www.linearcorp.com)

<sup>1</sup> Includes One (1) **P-300HA** 125 kHz, HID-Compatible, Proximity Access Card Reader (Part # 620-100224)


<sup>2</sup> Includes Four (4) **P-300HA** 125 kHz, HID-Compatible, Proximity Access Card Readers (Part # 620-100224)

# Become a 60 Second Expert

Everything you need to know to build a basic eMerge system in less than a minute.

## Six-Door System


- A** One (1) **EL36-4MB**<sup>2</sup> 4-Door, 4-Reader Elite Access System Bundle (Part # 620-100259)
- B** One (1) **ACM2DB**<sup>3</sup> 2-Door, 2-Reader ACM with Reader Bundle (Part # 620-100270); ACM mounts inside either the ES or EL standard metal enclosure
- C** One (1) **ProxCARD II** 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARD II)



**eMERGE**  
ELITE-36

## Eight-Door System

- A** One (1) **EL36-4MB**<sup>2</sup> 4-Door, 4-Reader Elite Access System Bundle (Part # 620-100259)
- B** One (1) **ACM4DB**<sup>2</sup> 4-Door, 4-Reader Access System Bundle (Part # 620-100272); ACM mounts inside either the ES or EL standard metal enclosure
- C** One (1) **ProxCARD II** 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARD II)



**eMERGE**  
ELITE-36

## Ten-Door System

- A** One (1) **EL36-4MB**<sup>2</sup> 4-Door, 4-Reader Elite Access System Bundle (Part # 620-100259)
- B** One (1) **EXN-2CB**<sup>3</sup> 2-Door, 2-Reader Access System Expansion Bundle (Part # 620-100275)
- C** One (1) **ACM4DB**<sup>2</sup> 4-Door, 4-Reader Access Control Module Bundle (Part # 620-100272); ACM mounts inside either the ES or EL standard metal enclosure
- D** One (1) **ProxCARD II** 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARD II)



**eMERGE**  
ELITE-36

ES = eMerge Essential

EL = eMerge Elite

<sup>2</sup> Includes Four (4) **P-300HA** 125 kHz, HID- and AWID-Compatible, Proximity Access Card Readers (Part # 620-100224)

<sup>3</sup> Includes Two (2) **P-300HA** 125 kHz, HID- and AWID-Compatible, Proximity Access Card Readers (Part # 620-100224)

**Linear**<sup>®</sup>

800.421.1587 | www.linearcorp.com