What d	o I have?	
quantity	description	item
1	5200 series strike body	1
1	Trim enhancer	3
2	Trim enhancer screws #4-40 x 1/8	6
5-11	Blue wire connectors	0
1	Pig tail connector	

## What do I need? . . .

You will ne	ed 1 faceplate option kit (not in	cluded, see page 3) which contains:			
quantity	description	item			
1	5000 series faceplate				
2	Mounting screws #12-24 x 1/2	4			
2	Faceplate screws #8-32 x 5/8	5			
What to	ols would you rec	ommend I use?			
	ļ				
*tool may diffe	er on different applications				





3

## Caution

Before connecting electric strike at the installation site verify input voltage using a multimeter. Any input voltage exceeding 10% of the solenoid rating may cause severe damage to the unit.

## What item are you looking for?






(3) Trim enhancer (5) (sold with faceplate option kit) (6) Trim enhancer screws

#### (Step 1)

Electrica	l ratings fo	or the	5200	):	
strike wiring configuration	12V - 16V		24V		
resistance	50 Ohms		200 Ohms		
continuous duty 10.8VDC - 13.2VDC .22 Amps27 Amps			21.6 VDC - 26.4 VDC .1 Amps13 Amps		
intermittent dut -	uty 10% max duty cycle. (2 minu 10.8 VDC - 17.6 VDC .22 Amps35 Amps 12 VAC - 17.6 VAC .24 Amps35 Amps		ute max on time). 21.6 VDC - 26.4 VDC .1 Amps13 Amps 24 VAC - 26.4 VAC .12 Amps13 Amps		
	mum Wire		Solenoid	l Voltage	
Gauge Requirements		12V	- 16V	24V	
200 f	eet or less	18 gauge		20 gauge	
200 t	o 300 feet	16 gauge		18 gauge	
300 to 400 feet		14 gauge		16 gauge	

### Step 2





### **Installer Hint**

The wires do not need to be stripped, insert wires into the blue wire connector, crimp with pliers, and you are finished.

#### Step 3

## Is your frame already prepared?

If the answer is **yes** continue to step 4.


If the answer is **no** see frame prep example pages 11-12.

### Step 4

## Is a pigtail already attached?

If the answer is **yes** continue to step 5.

If the answer is **no** please follow the instructions below.




#### Step 5

## What does the strike wiring configuration need to be?

If the answer is **12 - 16\* Volt** continue to step 6.

If the answer is **24 Volt** please follow the instructions below.





## Installer Hint

When adjusting the screws for field selectability, veteran installers suggest adding a drop of Loctite<sup>®</sup> to the screws before tightening them into their final position for added durability.

### Step 6

## Do you use Standard, LBM, or LBSM?

If the answer is **standard** continue to step 7.


If the answer is  $\ensuremath{\textbf{LBM}}$  follow the instructions under step 6a.

If the answer is  $\ensuremath{\textbf{LBSM}}$  follow the instructions under step 6b.

## Step 6a

## What is LBM?

**LBM** stands for Latch Bolt Monitoring. The **LBM** option detects that the Latch is captured in the Strike.



## Step 6b What is LBSM?


LBSM stands for Latch Bolt Strike Monitoring. The LBSM option additionally detects the position of the keeper. wiring diagram white common LBM orange normally open green normally closed LBSM brown common blue normally open vellow normally closed,



When using the trim enhancer you will need to make the cutout slightly larger than the actual dimensions given for the strike. This will allow space for the trim enhancer.

## Step 8

## How do I attach the faceplate?



### Step 9


## Do you want to use a trim enhancer?

The **trim enhancer** allows the installer to cover up a rough or incorrect sized frame cut.

If the answer is **no** continue to step 10.

If the answer is **yes** please follow the instructions below.





### Step 7

## Do you need fail secure or fail safe?

If the answer is **fail secure** follow the instructions under step 7a. If the answer is **fail safe** follow the instructions under step 7b.

## Step 7a)

## What is fail secure?

All HES strikes come standard as **fail secure**. (as shown)

**Fail secure** means if the strike loses power it remains locked.

### If you need to convert the strike to fail secure

(a) Loosen screws, but do not remove them.

(b) Move screws into fail secure position.

(c) Tighten scews.

## Step 7b

## What is fail safe?

Fail safe means if the strike loses power it remains unlocked.


**(b)** 

#### If you need to convert the strike to fail safe


(a) Loosen screws, but do not remove them.

(b) Move screws into fail safe position.

**(c)** Tighten scews.








If binding between the latchbolt and keeper occurs you may need to horizontally adjust the electric strike.

## Step 11


## Do you need to make horizontal adjustments?

If the answer is **no** you are finished with the installation process. If the answer is **yes** please follow the instructions below.



(a) Slowly turn the horizontal adjustment screws to adjust the strike in-frame. Do not remove the screws or completely rotate them more than 3 full turns.

**(b)** Once the strike has been adjusted, securely tighten the screws. This will allow the K-nut's teeth to dig into the strike housing to prevent slippage during use.



## Want to simplify the process?

HES offers a universal **Metal Template Kit** to simplify the installation procedure. Order model 154-MTK by calling customer support at 800.626.7590.




## Installer Hint

ALWAYS use eye and ear protection

Veteran installers recommend cutting inside the lines and finishing the cutout with a metal file.


#### Frame preparation example\*



\*Note: Frame example with ANSI 4 7/8" x 1 1/4" strike preparation

## 501 faceplate option

## What should the cutout be?






### **Installer Hint**

To obtain the best results, always cut well inside the lines and use a metal file to finish off the cutout.


## **(501 faceplate option)**

What are the faceplate dimensions?




It is often beneficial to first put masking tape on the door frame where you will be installing the electric strike. The masking tape protects the frame surface from being scratched during the installation process.

### 501A faceplate option



501A faceplate option


## What are the faceplate dimensions?






Veteran installers suggest removing all dust and debris before final installation of the electric strike.

### **501B faceplate option**



## What are the faceplate dimensions?





(18)



To obtain the best results when preparing a wood frame for an electric strike installation; cut a 1/4'' area around the inside of the template dimensions first with a wood chisel or router for a clean finished edge.

## 502 faceplate option What should the cutout be?






**•** For wood applications pre-drill pilot hole for mounting points with a #11 drill bit.


#### 502 faceplate option


What are the faceplate dimensions?



## **Installer Hint**

Cutting an aluminum frame with a router or a jigsaw can be very messy and noisy. Spread out a drop cloth in front of your work area to capture the aluminum chips and bring a vacuum to clean up after your installation.









Veteran installers suggest masking the frame off with tape. This allows you to mark your guides on the tape instead of the frame. Then after you cut the frame you simply need to remove the tape for a clean finish.


## 503/503B\* faceplate option





#### 504 faceplate option






### **Installer Hint**

To obtain the best results when preparing a wood frame for an electric strike installation; cut a 1/4" area around the inside of the template dimensions first with a wood chisel or router for a clean finished edge.

### 504 faceplate option



# What are the faceplate dimensions?