



941263-00

LD Kit

33/99

VON DUPRIN®


Installation Instructions

1. Read 33/99 Device **INSTALLATION INSTRUCTIONS**.
2. Replace existing cover plate with **LD cover plate**. Install **LD cover plate** ensuring **cover bearing insert** is against touchbar.
3. Cut 33/99 Device to proper length using cutoff chart on Device direction sheet. (Be careful not to cut the **anti-rattle spring**)
4. Install Device.
5. Install mechanism case end cap.

RETROFIT INSTALLATION - INSTRUCTIONS

1. Remove mechanism case end cap.
2. Remove existing cover plate.
3. Cut **LD cover plate** to same length as existing cover plate that has been cut to size. (Be careful not to cut the **anti-rattle spring**)
4. Install **LD cover plate** ensuring **cover bearing insert** is facing touchbar.
5. Install mechanism case end cap.

FOR CUTOUTS ON INSIDE FACE OF DOOR
SEE DIRECTIONS IN DEVICE CARTON.



Customer Service

1-877-671-7011 www.allegion.com/us

DISTRIBUTED BY



ACCESS HARDWARE SUPPLY
accesshardware.com



© Allegion 2014
Printed in U.S.A.
941263-00 Rev. 01/14-b