


PT200 & PT1000 POWER TRANSFER TEMPLATE

☉ OF PT IN FRAME MUST ALIGN
 WITH ☉ OF PT IN DOOR

WOOD:
 HOLES PREPARED
 DURING INSTALL
 METAL:
 #10-24 TAPPED HOLE
 12 PLACES

RECOMMENDED 6" BELOW UPPER HINGE
 ON DOORS UP TO 7'0" HIGH.
 LOCATE 24" BELOW UPPER HINGE ON DOORS
 OVER 7'0" TO 10'0" HIGH.
 NOTE: FOR WOOD FIRE DOOR, CONSULT
 DOOR MANUFACTURE FOR APPROVED LOCATION.



ELECTRICAL RATINGS

PT200	(2) 18 AWG WIRES-MAX. RATING 24VDC, 5A OR 120VAC NEC CLASS 3
PT1000/PT1000EZ	(10) 24 AWG WIRES-MAX. RATING 24VDC, 1A
PT1200/PT1200EZ	(10) 24 AWG WIRES-MAX. RATING 24VDC, 1A, (2) 18 AWG WIRES-MAX. RATING 24VDC, 5A OR 120VAC NEC CLASS 3
PTC5E	CAT-5E CABLE WIRE, (8) 24 AWG WIRES, (1) 22 AWG WIRE

PT200 & PT1000-INSTALLATION-03.DWG



www.abhmfg.com
 E-mail: abhinfo@abhmfg.com
 Architectural Builders Hardware Mfg., Inc.
 1222 Ardmore Ave., Itasca, IL 60143
 630.875.9900; FAX 800.9FAXABH (932.9224)

PT200 & PT1000

© 2013 ABH Mfg., Inc.
 printed in USA

REVISED 06-14-13